PREMIER®

MANUAL DE INSTRUCCIONES
TELÉFONO CELULAR C/TV
CEL-4456TV

ESTIMADO CLIENTE

Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia.
Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

ÍNDICE

INSTRUCCIONES DE SEGURIDAD 3
RECOMENDACIONES 3
DESCRIPCIÓN GENERAL 4
ESPECIFICACIONES TÉCNICAS 5
INSTRUCCIONES DE OPERACIÓN 5
INSTALACIÓN DE TARJETA SIM 5
INSTALACIÓN DE LA TARJETA T-FLASH 6
BATERÍA 6
ENCENDER Y APAGAR EL CELULAR 7
CONECTARSE A UNA RED 8
LLAMADAS 8
AUDÍFONOS 8
MODOS DE ENTRADA 8
OPERACIÓN DEL MENÚ 9
MENSAJES 9
AGENDA TELEFÓNICA 10
CALENDARIO 11
HISTORIAL DE LLAMADAS 11
BLUETOOTH 11
SERVICIOS 11
CONECTIVIDAD 11
MULTIMEDIA 12
ADMINISTRADOR DE ARCHIVOS 13
CONFIGURACIÓN 13
PANTALLA 15
ORGANIZADOR 15
PERFIL DE USUARIO 16
JUEGOS 16
REDES 16
RESOLUCIÓN DE PROBLEMAS 17

PRECAUCIÓN

RIESGO DE CHOQUE ELÉCTRICO , NO ABRA

Precaución: Para reducir el riesgo de choque eléctrico, no retire la cubierta, no hay partes manipulables por el usuario al interior de la unidad. Refiera todo mantenimiento o intervención técnica a personal técnico calificado.

Este símbolo indica la existencia de voltaje peligroso al interior de esta unidad, que constituye un riesgo de choque eléctrico.

Este símbolo indica que hay importantes instrucciones de operación y mantenimiento en la literatura que acompaña a esta unidad.

LÍNEAS DE SERVICIO AL CLIENTE PREMIER

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panamá:	300-5185
Sitio Web:	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTA

Nos reservamos el derecho de modificar las especificaciones, características y/u operación de este producto sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

⚠ INSTRUCCIONES DE SEGURIDAD

- Si pierde su teléfono celular o ha sido robado notifique a su empresa de comunicaciones para que se haga el bloqueo y trámite respectivo. Esto puede evitar pérdidas económicas debido a un uso no autorizado.
- Utilice el sistema de clave para bloquear su teléfono al igual que el código PIN de la tarjeta SIM.
- No utiliza el teléfono celular mientras conduce. Utilice el sistema manos-libres cuando sea necesario.
- Los dispositivos inalámbricos pueden causar interferencia en aviones. Apague su teléfono celular durante un vuelo.
- Apague su equipo en lugares susceptibles de explosión tales como estaciones de gas o plantas químicas, entre otros.
- Siga las normas en lugares como hospitales o donde pueda causar interferencia. Tenga precaución en no usa el equipo cerca de aparatos médicos tales como marcapasos, ayudas auditivas y algunos otros dispositivos médicos electrónicos.
- La calidad de la conversación en un teléfono celular puede verse afectada por interferencia de radio. El equipo cuenta con una antena incorporada ubicada debajo del micrófono. No toque el área de la antena durante la conversación para evitar que la calidad se deteriore.
- El equipo debe ser instalado o reparado únicamente por personal autorizado.
- Utilice únicamente accesorios y baterías aprobadas.
- De a su teléfono celular un uso adecuado y evite golpearlo.
- Recuerde que puede utilizar el equipo para hacer llamadas de emergencia de acuerdo con la configuración local.

⚠ RECOMENDACIONES

- Este es un equipo de alta calidad. Úselo con precaución para prolongar su vida útil.
- Mantenga el equipo fuera del alcance de los niños.
- Mantenga el equipo seco. Evite que este húmedo y se moje con la lluvia u otros líquidos ya que esto puede oxidar los circuitos electrónicos.
- No use ni almacene un el equipo en lugares con mucho polvo.
- No guarde el equipo en lugares con altas temperaturas ya que pueden reducir la vida útil de los circuitos electrónicos al igual que dañar la batería y algunas partes plásticas.
- Tampoco guarde el equipo en un lugar muy frío ya que puede generarse condensación en los circuitos electrónicos que podrían dañarse.
- Evite que el equipo se golpee con el fin de proteger los circuitos.

DESCRIPCIÓN GENERAL

FUNCIONES DE LOS BOTONES

Marcar Presione este botón para hacer una llamada introduciendo el número que se desea marcar o seleccionando un contacto de la agenda. También puede presionarlo para recibir una llamada entrante o para conocer el registro de las últimas llamadas realizadas.

Finalizar Presione este botón para terminar una llamada entrante o saliente. También puede usarlo para salir del menú y regresar al modo de espera. Manténgalo presionado por dos o tres segundos para encender o apagar el teléfono celular.

Derecha/Izquierda Utilice estos botones que representan las funciones que se muestran en la parte inferior de la pantalla encima de cada botón.

Botón de Dirección Presione este botón para moverse a través de las opciones cuando se está buscando en una lista. En el modo de edición presione este botón para navegar.

Confirmar Presione este botón para confirmar su selección. En el modo de espera, mantenga presionado este botón por unos segundos para encender y apagar la lámpara la cual está ubicada en la parte superior del teléfono.

Borrar Presione este botón para borrar un carácter antes del cursor.

Línea de Alimentación Este botón ayuda a cambiar a otra línea cuando hay interferencia en la interface de edición.

Shift Presione este botón para cambiar entre otros modos de entrada.

Barra de Espacio Presione este botón en la interface de edición para introducir un espacio en blanco. En la interface de espera, presione este botón de manera prolongada para apagar o encender la lámpara ubicada en la parte superior del teléfono.

Sym Presione este botón en la interface de edición para introducir símbolos.

Mayúsculas Presione este botón para cambiar entre mayúsculas y minúsculas.

Alt En la interface de edición, presione este botón para introducir un símbolo o número alternativo.

Botones numéricos y Letras Presione estos botones para introducir los caracteres correspondientes.

ESPECIFICACIONES TÉCNICAS

Dimensiones	56.73 × 104.5 × 14.3
Peso	Con batería: 74g - Sin batería: 64g
Capacidad de Batería del Litio	650 mAH
Duración Continua en Modo de Espera	75 horas
Duración Continua en Conversación	3.5 horas

INSTRUCCIONES DE OPERACIÓN

INSTALACIÓN DE TARJETA SIM

Una tarjeta SIM contiene información útil, incluyendo su número de teléfono celular, PIN (Número de Identificación Personal), PIN2, PUK (clave de desbloqueo del PIN), PUK2 (clave de desbloqueo del PIN2), IMSI (Identidad Internacional del Suscriptor de Celular), información de red, datos de contactos y mensajes de texto.

Nota: Después de apagar su teléfono celular espere unos segundos antes de retirar o volver a poner una tarjeta SIM. Tenga precaución al manipular la tarjeta SIM, ya que la fricción o doblar la tarjeta puede dañarla. Mantenga la tarjeta SIM fuera del alcance de los niños.

INSTALACIÓN

1. Apague el teléfono celular.
2. Retire la tapa posterior.
3. Retire la batería.
4. Inserte la tarjeta SIM en la ranura correspondiente alineándola con la forma que allí se observa y con la superficie metálica hacia abajo.
5. Coloque de nuevo la batería teniendo en cuenta el punto de contacto.

USO DEL CÓDIGO

El teléfono celular y la tarjeta SIM soportan diferentes tipos de clave con el fin de prevenir el uso inadecuado. Cuando el teléfono le pida que introduzca alguno de esos códigos simplemente escríbalo y presione el botón de aceptar (OK). Si coloca un código equivocado presione la tecla derecha para borrarlo y luego introduzca el código correctamente.

CÓDIGO DE BLOQUEO DE TELÉFONO

Este código puede utilizarse para prevenir que su teléfono celular sea usado de manera inapropiada. Por lo general, este código es proporcionado junto con el equipo por parte del fabricante. El código inicial de bloqueo es 1234. Si usted activa el código de bloqueo deberá introducirlo cuando encienda el teléfono.

CÓDIGO PIN

El código PIN (Número de Identificación Personal, de 4 a 8 dígitos) previene que su tarjeta SIM sea utilizada por personas no autorizadas. Por lo general el PIN es suministrado junto con la tarjeta SIM por parte del operador de telefonía. Si este activa la función de PIN deberá introducirlo cada vez que encienda su teléfono celular.

La tarjeta SIM se bloqueará sistema introduce el código PIN erróneamente tres veces seguidas. Para desbloquear debe hacer lo siguiente:

1. Introduzca el código correcto PUK siguiendo las instrucciones en pantalla.
2. Luego introduzca el nuevo PIN y presione OK.
3. Introduzca una vez más el nuevo PIN y presione OK.
4. Si el código PUK es el correcto, la tarjeta SIM se desbloqueará y el código PIN se reiniciará.

Nota: La tarjeta SIM se bloqueará al introducir el código PIN erróneamente tres veces seguidas. Para desbloquearla debe introducir el código PUK el cual se obtiene a través de su operador de telefonía.

CÓDIGO PUK
El código PUK (Clave de Desbloqueo Personal) se requiere para cambiar un PIN bloqueado. Este viene junto con la tarjeta SIM. En caso contrario contacte a su operador de telefonía. Si usted introduce el código PUK de manera incorrecta 10 veces, la tarjeta SIM será inválida. Deberá entonces contactar a su operador de telefonía para reemplazar la tarjeta SIM.

CÓDIGO DE RESTRICCIÓN
Este código se requiere cuando desee ajustar la función de restricción de llamadas. Usted puede obtener este código de su operador de telefonía para ajustar la función.

INSTALACIÓN DE LA TARJETA T-FLASH
La tarjeta T-flash es una tarjeta móvil de almacenamiento que se encuentra dentro del teléfono celular. Para instalar la tarjeta T-flash abra el pestillo que cubre la ranura, insértela en ella y cierre el pestillo.

Nota: Es posible que el teléfono celular no pueda reconocer de manera automática la tarjeta T-flash que se inserta en él cuando el teléfono se encuentra encendido. Debe apagar el teléfono celular y luego encenderlo. De esta forma se puede reconocer la tarjeta T-flash. Tenga en cuenta que esta tarjeta es un objeto muy pequeño. Manténgalo fuera del alcance de los niños.

BATERÍA
La batería del litio que viene con el teléfono celular puede instalarse de inmediato una vez desempaque el equipo.

INDICACIÓN DE NIVEL
El teléfono celular puede monitorear y mostrar el estado de la batería. Normalmente la energía restante de la batería se muestra con un icono en la parte superior derecha de la pantalla. Cuando la energía es insuficiente el teléfono mostrará el mensaje “batería baja”. Si usted ha instalado un sonido de alerta, entonces éste se activará para indicárselo.

Cuando la batería se esté cargando se observará una animación en pantalla. Cuando la carga termine esta animación desaparecerá.

CARGAR LA BATERÍA

- Coloque la batería en el teléfono antes de cargarla.
- Conecte el cargador al celular y asegúrese de que esté bien conectado.
- Conecte el otro extremo a la fuente de energía.
- Durante la carga el icono de batería se mantiene parpadeando hasta que esté cargada completamente. Es normal que la batería se caliente un poco durante este periodo. Una vez que la carga termine el icono dejará de parpadear.

Nota: Asegúrese de que los enchufes del cargador, los audífonos y el cable USB se conecten en la dirección adecuada. Conectarlos en la dirección equivocada puede causar problemas de carga u otros problemas. Antes de iniciar la carga asegúrese de que el voltaje y la frecuencia de la corriente corresponden con el voltaje y potencia del cargador.

USO DE LA BATERÍA

El desempeño de la batería depende de múltiples factores: configuración de la red, fuerza de la señal, temperatura ambiente, funciones o configuraciones, accesorios del teléfono, y el uso de las aplicaciones de voz y datos. Para garantizar el óptimo desempeño de su batería tenga en cuenta lo siguiente:

- Utilice únicamente la batería proporcionada por el fabricante. De lo contrario pueden generarse problemas de carga o daños.
- Apague el teléfono celular antes de quitar la batería.
- El proceso de carga tarda un poco más para una batería nueva o para una batería que no se ha usado por bastante tiempo. Si el voltaje de la batería es muy bajo para permitir que el equipo encienda, cargue la batería por un tiempo más largo. En este caso, el icono de batería no parpadeará hasta que la batería entre en modo de carga.
- Durante la carga asegúrese de que la batería está colocada en un espacio a temperatura ambiente.
- Si observa que la batería tiene algún tipo de daño como por ejemplo olor, calor excesivo, rupturas o fuga de líquido, detenga su uso de inmediato.
- La batería se gasta con el uso. Se necesitará mayor tiempo de carga en la medida en que la batería se use por más tiempo. Si usted observa que el tiempo de conversación se reduce, pero se está usando más tiempo en cargar la batería y en apariencia está cargada adecuadamente, es recomendable adquirir una nueva batería de un proveedor reconocido.

Nota: Para garantizar la seguridad personal y proteger el medio ambiente no deseche la batería con la basura común. Regrésela al fabricante o deposítela en un lugar adecuado en su área.

Precaución: Un cortocircuito en la batería puede causar una explosión, fuego, lesiones personales u otras consecuencias.

ENCENDER Y APAGAR EL CELULAR

Presione el botón de Finalizar Llamada por unos segundos para encender el equipo. Aparecerá una animación en pantalla. Si el teléfono solicita el código de desbloqueo, introdúzcalo y presione la tecla Aceptar (OK). El código original es 1234. Introduzca el código PIN si el equipo lo solicita. Después de estos pasos el equipo entra en el modo de espera. Para apagar el equipo presione nuevamente por varios segundos el botón de Finalizar Llamada.

CONECTARSE A UNA RED

Una vez que la tarjeta SIM y el teléfono estén correctamente desbloqueados, el teléfono buscará automáticamente una red disponible. Una vez que la encuentre el teléfono entra a modo de espera. Cuando el teléfono se registre en la red el nombre del operador aparecerá en la pantalla. En este punto usted podrá hacer y recibir llamadas normalmente.

LLAMADAS

En el modo de espera utilice los botones numéricos e introduzca el código de área y el número telefónico al que desea llamar. Luego presione el botón de marcar. Para finalizar, presione el botón de finalizar llamada.

LLAMAR DE UN NÚMERO DE LA AGENDA

Entre a su agenda telefónica en el equipo y utilice los botones arriba y abajo para encontrar el número que desea marcar. Presione el botón de llamar y el equipo iniciará automáticamente la llamada.

REMARCAR EL ÚLTIMO NÚMERO

En el modo de espera presione el botón de llamar para mostrar las llamadas realizadas. Utilice los botones arriba abajo para seleccionar el número que desea marcar y presione el botón de llamar.

CONTESTAR LLAMADAS ENTRANTES

Presione el botón de llamar o el botón izquierdo para contestar las llamadas entrantes. Presione el botón de finalizar llamada para terminar la conversación. Para rechazar una llamada entrante presione el botón de finalizar llamada o el botón derecho.

Nota: Si el número telefónico y el nombre de la persona que está llamando se encuentra registrado en la agenda, el equipo mostrará en pantalla estos datos y así usted sabrá quién está llamando. Si no está registrado entonces solamente se mostrará el número. Si usted está revisando su agenda o navegando en su teléfono aún puede contestar llamadas entrantes.

AUDÍFONOS

Al conectar los audífonos el equipo entrará automáticamente en modo de audífonos. Asegúrese de insertarlos adecuadamente para que funcionen correctamente.

MODOS DE ENTRADA

Este teléfono celular proporciona dos modos de entrada incluyendo modo en inglés y modo numérico. Usted puede utilizar estos modos cuando esté introduciendo datos en la agenda, mensajes de texto, archivos y saludo de bienvenida.

ÍCONOS PARA MÉTODOS DE ENTRADA

Después de entrar en la ventana de edición, ya sea en la agenda, mensajes de texto o memorando, se mostrará un icono en pantalla para indicar el modo de entrada activo:
Modo numérico: “123”
Modo en inglés en mayúsculas: “ABC”
Modo en inglés en minúsculas: “abc”

CAMBIAR ENTRE MODOS DE ENTRADA
Presione el botón Control para cambiar el modo de entrada.

MODO NUMÉRICO
En este modo usted puede introducir directamente los números. La siguiente tabla muestra los números correspondientes a cada letra cuando se está en el modo numérico.

Letra	Número
W	1
E	2
R	3
S	4
D	5
F	6
Z	7
X	8
C	9
0	0
*	A*
#	Q#

OTRAS FUNCIONES
Para introducir un espacio en blanco, presione la barra espaciadora.
Para corregir datos presione el botón de borrar.
Para insertar un símbolo presione el botón símbolo y seleccione el que desea.

OPERACIÓN DEL MENÚ

MENSAJES
Esta función le permite controlar todo lo relacionado con los mensajes. Escribir, enviar, borrar. Si la memoria de mensajes está llena aparecerá un icono en pantalla parpadeando. Para recibir mensajes normalmente usted deberá borrar algunos de los mensajes ya existentes.

ESCRIBIR MENSAJE
Entre a este menú para crear un mensaje de texto o un mensaje multimedia.

BUZÓN DE ENTRADA
Los mensajes recibidos se ven en este menú.

BORRADORES
En esta función usted puede guardar mensajes para enviarlos después o crear plantillas.

BUZÓN DE SALIDA
Los mensajes enviados se guardan en este menú.

BORRAR MENSAJES
Usted puede borrar mensajes almacenados en el buzón de entrada, en el buzón de salida, en borradores, etc., con esta función.

MENSAJES DE DIFUSIÓN
El servicio de red permite que usted reciba una variedad de mensajes de texto, como por ejemplo, mensajes de difusión acerca del clima o las condiciones de las vías. Actualmente, sólo algunos operadores de telefonía proporcionan este servicio. Póngase en contacto con su operador de telefonía para más información.

- **Modo de Recibir:** actívelo o desactívelo para permitir esta función.
- **Configuración de Canal:** seleccione el recibir algunos tipos de mensajes de difusión o edite algunos números de canal.
- **Idiomas:** seleccione el idioma en el cual quiere mostrar el mensaje de difusión. El idioma seleccionado, sin embargo, puede no estar disponible para su operador de telefonía.
- **Leer Mensaje:** ver los mensajes de difusión. Utilice los botones arriba y abajo para ver los mensajes.

CONFIGURACIÓN DE MENSAJE
Esta función permite configurar las características de los SMS, MMS y el servicio de mensajería

AGENDA TELEFÓNICA
El teléfono celular puede almacenar hasta 300 números telefónicos. El número de teléfonos que una tarjeta SIM puede almacenar depende de la propia capacidad de la tarjeta. Los números telefónicos almacenados en el teléfono celular y la tarjeta SIM conforman la agenda telefónica. Después de seleccionar un número telefónico en esta agenda, seleccione Opciones para llevar a cabo las siguientes operaciones:

- **Ver:** ver el contenido del número telefónico.
- **Enviar mensajes de texto:** envía el mensaje de texto al número seleccionado.
- **Enviar mensaje multimedia:** envía el mensaje multimedia al número seleccionado
- **Llamar:** llama al número seleccionado.
- **Marcación IP:** marcación IP del número seleccionado.
- **Edición:** edita el número telefónico y el nombre.
- **Borrar:** borra el número telefónico de la agenda.
- **Copiar:** duplica el número telefónico del teléfono celular a la tarjeta SIM o viceversa.
- **Mover:** mueve el número telefónico del teléfono celular a la tarjeta SIM o viceversa.
- **Enviar tarjeta de presentación:** seleccione y envíe información de contactos a otras personas a través de mensajes de texto, mensaje multimedia o Bluetooth.
- **Marcar varios:** puede seleccionar varios números telefónicos a la vez de tal manera que pueda llevar a cabo la misma operación en ellos.
- **Grupos de llamada:** puede asignar contactos a los cinco grupos de llamadas que vienen de fábrica. Para cada grupo usted puede evitar el nombre, colocar una alerta de llamada, asignar un ringtone o establecer una imagen.
- **Configuración de agenda:** ajusta algunos parámetros de la agenda telefónica.

CALENDARIO

En este menú usted puede observar un calendario mensual con el fin de hacer seguimiento a eventos importantes, etc.

HISTORIAL DE LLAMADAS

Con esta función usted puede ver una lista de llamadas perdidas, hechas y recibidas.

BLUETOOTH

Con esta función usted puede llevar a cabo una conexión inalámbrica con otros dispositivos compatibles, tales como teléfonos celulares, computadores, audífonos y equipos de automóvil. Usted puede utilizar el Bluetooth para enviar imágenes, videos, música archivos de audio y notas, y transferir archivos desde su computador compatible.

Nota: al utilizar conexión móvil con otro dispositivo vía Bluetooth es probable que el equipo le solicite una contraseña. Introducir una contraseña incorrecta dará como resultado una colección fallida. Por lo general, la contraseña se puede decidir por uno de los equipos participantes. En caso contrario, cuando se conecte por ejemplo a unos audífonos Bluetooth, la contraseña sería la correspondiente a los audífonos Bluetooth.

SERVICIOS

INTERNET

Esta función le permite entrar a Internet. Su teléfono celular le preguntará el modo en el cual desea entrar.

- **Página de inicio:** indica la página inicial de Internet.
- **Favoritos:** se utiliza para guardar los sitios web utilizados comúnmente.
- **Introducir dirección:** introduzca la dirección web que desea buscar y presione el botón de finalizar para entrar directamente.
- **Última página web:** usted puede ver la última dirección web a la cual entró con esta función.
- **Páginas recientes:** navegue por el registro de las páginas buscadas recientemente.
- **Configuración:** configurar el servicio WAP relacionado.

Nota: consulte a su operador de telefonía con relación a las tarifas y configuración específica.

STK

El servicio STK es el juego de herramientas de la tarjeta SIM. Este teléfono tiene soporte para la función de servicio. Los ítems específicos dependen de la tarjeta SIM y la red. El menú de servicio será auto agregado al menú del teléfono cuando tenga soporte de red y tarjeta SIM.

CONECTIVIDAD

En esta interface puede ajustar parámetros relacionados con los datos de la cuenta.

MULTIMEDIA

CÁMARA
El teléfono celular cuenta con una cámara la cual soporta las funciones fotográficas. Gire el teléfono para aliviar la cámara con la imagen y presione OK para tomar la foto. En el modo de captura puede utilizar los botones de dirección derecha o izquierda para ajustar los valores de exposición, y los botones de dirección arriba y abajo para acercar y alejar.

VIDEOGRABADORA
Esta función le permite grabar videos. Presione OK para comenzar a grabar. En el modo de captura puede utilizar los botones de dirección derecha o izquierda para ajustar los valores de exposición, y los botones de dirección arriba y abajo para acercar y alejar.

TELEVISIÓN
Con esta función usted puede observar programas de televisión y agregar canales a la lista de canales. Seleccione un lugar de recepción adecuada de señal y sintonice los diferentes canales. Utilice el botón * (asterisco) para hacer una búsqueda automática, el botón # para entrar a modo de pantalla completa, y presione I/- o O/+ para ajustar el volumen.

RADIO FM
Utilice el equipo como un radio tradicional de FM con sintonización automática y capacidad para guardar estaciones. En la interface de radio FM utilice los botones de dirección derecha/izquierda para moverse manualmente a través de las estaciones, el botón de dirección abajo para pausar o activar la reproducción de la estación en curso, y el botón de dirección hacia arriba para permitir la auto-búsqueda (una vez que se active, usted puede presionar los botones de dirección derecha/izquierda para buscar las estaciones automáticamente). Presione I/- o O/+ para ajustar el volumen.

REPRODUCTOR DE AUDIO
Utilice esta función para reproducir archivos de audio. Utilice los botones de dirección para controlar el proceso de reproducción. Play/pausa (botón arriba); cambiar entre canciones hacia adelante y hacia atrás (botones derecha e izquierda); adelantar (botón derecha mantenido); retroceder (botón izquierdo mantenido); detener (botón abajo); lista de reproducción (botón OK). Presione I/- o O/+ para ajustar el volumen. Formatos soportados: amr, midi, mp3, wma, wav.

VISOR DE IMÁGENES
Con esta función usted puede ver las imágenes.

REPRODUCTOR DE VIDEO
Con esta función usted puede ver los videos grabados por la cámara o que han sido guardados en el equipo. Archivos MP4 y formato AVI. Con los botones de dirección usted puede controlar el proceso de reproducción. Play/Pausa (botón OK); adelantar (botón derecho mantenido); retroceder (botón izquierdo mantenido). Presione I/- o O/+ para ajustar el volumen. Presione el botón # para ir a modo de pantalla completa.

GRABADORA DE SONIDOS
El equipo soporta los formatos WAV y AMR. El formato AMR retira la compresión algorítmica. Así que en la misma condición de memoria no requiere mayor tiempo de grabación el formato WAV.

CALCULADORA
Utilice la calculadora para hacer operaciones matemáticas sencillas. Sumar, restar, multiplicar y dividir. Presione los botones de dirección arriba (+), abajo (-), izquierda (x), derecha (÷), para seleccionar la operación matemática. Presione el botón suave derecho para borrar la cifra.

ADMINISTRADOR DE ARCHIVOS

El teléfono proporciona cierta cantidad de espacio para usuarios para administrar archivos y soporte de la tarjeta T-flash. La capacidad de la tarjeta T-flash es seleccionable. Usted puede utilizar el administrador de archivos para manejar adecuadamente varios directorios de archivos en el teléfono y en la tarjeta T-flash.

ABRIR
Elija Administrador de Archivos para entrar al directorio raíz de la memoria. Este directorio mostrará una lista de carpetas predeterminadas, nuevas carpetas y archivos de usuario. Cuando el teléfono se enciende por primera vez o el directorio no ha sido modificado, el directorio raíz contiene únicamente las carpetas de fábrica.

FORMATO
Usted puede utilizar esta función para formatear todos los archivos en la memoria. El sistema volverá a crear una carpeta por defecto. Los datos formateados no pueden ser recuperados, así que es importante que usted esté seguro de que desea borrarlos.

CONFIGURACIÓN

CAMBIO DE SIM TRIPLE
Usted puede seleccionar manualmente que tarjeta SIM desea utilizar de acuerdo con sus necesidades.

CONFIGURACIÓN DE SIM TRIPLE
Usted puede hacer configuraciones para las tres tarjetas SIM en el teléfono celular.

CONFIGURACIÓN DE TELÉFONO

- **Fecha y Hora:** ajuste las cifras para la fecha y la hora y la hora adecuada de la ubicación. (Nota: al retirar la batería del teléfono celular o si ésta se descarga completamente, es probable que deba configurar de nuevo la hora y la fecha).
- **Programar encendido y apagado:** usted puede ajustar la hora cuándo desea que el teléfono celular se encienda o se apague automáticamente.
- **Idioma:** seleccione el idioma para el teléfono celular.
- **Modo de entrada:** seleccione un modo de entrada de acuerdo con sus necesidades.
- **Atajos:** con este menú usted puede seleccionar atajos para algunas funciones del teléfono en el modo de espera.

- **Modo de avión:** cuando se active esta función, se suspenderán muchas de las funciones de emisión de señal y no se podrán recibir llamadas ni mensajes de texto, mientras que puede hacer uso de otras funciones que no requieren la transmisión de señal, como por ejemplo, juegos, cámara y reproductor mp3.
- **Configuración UTRA:** Seleccione la SIM1 o la SIM2 según necesite.
- **Lámpara:** encienda y apague la lámpara. En el modo de espera presione y mantenga el botón OK para encenderla y apagarla.
- **Color LED:** encienda y apague el color LED según necesite.
- **Estilo de color LED:** hay tres estilos disponibles para elegir. Seleccione el que más le guste.

CONFIGURACIÓN DE LLAMADAS

- **Llamada en espera:** Después de escoger Activar, el teléfono contactará a su red. Un momento después, la red responderá enviará un mensaje de texto para acusar recibo a su operación. Si la función de llamada en espera está activa, la red le alertará y el teléfono celular mostrará en la pantalla el número de la llamada entrante si usted se encuentra en ese momento con otra llamada.
- **Desvío de llamadas:** esta función le permite desviar llamadas a otro número previamente especificado según necesite.
- **Bloqueo de llamadas:** esta función le permite bloquear llamadas según necesite. Cuando configure esta función usted necesita utilizar un código de bloqueo de llamadas de la red, el cual puede ser obtenido por su operador de telefonía. Si el código es incorrecto, un mensaje de error aparecerá en pantalla. Después de seleccionar la opción de bloqueo de llamadas, continúe para seleccionar activar o desactivar. El teléfono celular pedirá el código de bloqueo y luego contactará a su operador de telefonía. Un momento después, la red enviará una respuesta y los resultados de la operación al teléfono celular.
- **Cambio de línea:** usted puede cambiar entre la línea 1 y 2. Por defecto, la unidad está en la línea 1. (Nota: sistema elige la línea 2, puede que la marcación falle. Esto depende de la implementación de su operador de telefonía).
- **Remarcado automático:** puede activar o desactivar esta función. Cuando está activa el teléfono marcará de nuevo automáticamente el número telefónico después de un momento si la persona no contesta. Se puede ajustar el número de remarcado automático hasta 10 veces. En el periodo de remarcado automático no puede marcar otros números. Para finalizar el proceso presiona botón de finalizar. (Nota: esta función requiere soporte por parte del operador de telefonía donde se encuentra registrada la tarjeta SIM).
- **Marcación IP:** activa y desactiva la función de marcado IP y agrega/edita números IP.
- **Recordatorio de tiempo de marcación:** Para ajustar un tono sencillo o cíclico en una llamada para que usted sepa cuanto tiempo lleva.
- **Modo de contestar:** elige un modo de contestar según necesite.

CONFIGURACIÓN DE RED

Contacte a su operador de telefonía para obtener más información acerca de los servicios de red.

- **Selección de Red:** seleccione entre los modos automático y manual. Se recomienda el modo automático. Cuando la selección de red está en modo automático el teléfono celular tendrá preferencia por la red donde la tarjeta SIM está registrada. Cuando se selecciona el modo manual, usted debe elegir la red donde se encuentra registrada la tarjeta SIM.

- **Preferencias de red:** seleccione las preferencias de red. Por defecto, se mostrará la red donde la tarjeta SIM se encuentra registrada.

CONFIGURACIÓN DE SEGURIDAD
Esta función le permite hacer ajustes relacionados con el uso seguro.

Seguridad de SIM
- **Bloqueo de PIN:** para activar el bloqueo del PIN usted necesite introducir el código PIN correcto. Si se ajusta el bloqueo del PIN como activo deberá introducir el código PIN cada vez que encienda el teléfono celular. Como se mencionó anteriormente en el manual, ésta introduce el código PIN de manera incorrecta tres veces seguidas, deberá desbloquearlo con el código PUK.
- **Cambio de PIN:** cambia el código PIN de la tarjeta SIM.
- **Cambio de PIN2:** cambia el código PIN2 del código PIN.

Seguridad del Teléfono
- **Bloqueo de teléfono:** esta función le permite bloquear y desbloquear el teléfono. Una vez que se active la función usted deberá introducir la contraseña correcta cuando el teléfono se la solicite. La contraseña es de 4 a 8 dígitos.
- **Cambiar contraseña:** le permite cambiar la contraseña.
- **Bloqueo automático del teclado:** esta función le permite bloquear y desbloquear el teclado del teléfono. Usted puede ajustar un tiempo de bloqueado de 5 segundos, 30 segundos, 1minuto o 5 minutos. El teclado se bloqueará y los botones no estarán activos.

RESTAURAR CONFIGURACIÓN DE FÁBRICA
Esta función le permite restaurar la configuración inicial de fábrica. La contraseña preestablecida es 1234.

PANTALLA
El usuario puede seleccionar un fondo de pantalla, un protector de pantalla y ajustar el encendido y apagado de la pantalla.

ORGANIZADOR

CALENDARIO: En este menú usted puede observar un calendario mensual con el fin de hacer seguimiento a eventos importantes, etc.

ALARMA: El equipo cuenta con cinco alarmas que usted puede activar según necesite. Para cada alarma usted puede ajustar el ringtone y la hora.

CALCULADORA: Utilice la calculadora para hacer operaciones matemáticas sencillas. Sumar, restar, multiplicar y dividir. Presione los botones de dirección arriba (+), abajo (-), izquierda (x), derecha (÷), para seleccionar la operación matemática. Presione el botón suave derecho para borrar la cifra.

CRONÓMETRO: Con esta función usted puede medir diferentes tiempos.

PERFIL DE USUARIO

El teléfono celular proporciona diferentes perfiles de usuarios de tal forma que usted puede personalizar algunas funciones para adaptar el equipo a diferentes eventos y situaciones. Usted puede elegir entre los siguientes escenarios: General, Silencioso, Reunión, Exterior y Mi Estilo.

Cuando usted conecta unos audífonos al teléfono celular, el equipo entra automáticamente al modo de audífonos. No existe una opción de activación de los audífonos en la pantalla. Para más detalles sobre la operación, observe el perfil General. Sistema ajusta la configuración Audífonos -> Personalizado -> Modo de contestar -> Automático, las llamadas entrantes serán contestadas automáticamente.

ACTIVAR

Seleccione esta función para activar el modo seleccionado.

PERSONALIZAR

Después de seleccionar uno de los cinco modos anteriores, elija Personalizar para editar los siguientes ítems: tipo de alerta, tipo de timbre, ringtone de llamada entrante, volumen de ringtone, ringtone de mensajes, tono de teclado, encender/apagar tono, etc.

RESTAURAR

Utilice esta función para restaurar la configuración de fábrica de los perfiles de usuario.

JUEGOS

El equipo cuenta con un juego de carros de fórmula 1. Para más información sobre cómo jugarlo por favor refiérase a la ayuda del juego en el equipo.

REDES

Puede conectarse a las siguientes redes a través del internet:
Facebook, Ebbudy, Yahoo, Twitter.

RESOLUCIÓN DE PROBLEMAS

Esta lista es para ayudarle a resolver problemas simples que pueden presentarse en el uso del producto. Por favor léala y verifique estos puntos antes de solicitar ayuda de personal de servicio técnico autorizado.

PROBLEMA	CAUSA	SOLUCIÓN
Error de tarjeta SIM	La tarjeta SIM está dañada	Contacte su operador de telefonía
	La tarjeta SIM no está en posición	Verifique la posición de la tarjeta
	La parte metálica la tarjeta SIM sucia	Limpiela con una prenda suave
Recepción pobre de la señal	Obstrucción de la señal por otras ondas	Intente desplazarse a un lugar con mejor señal
	Congestión en la línea	Utilice el teléfono en horas de menos tráfico
El teléfono no enciende	La batería no tiene energía	Cargue la batería
No se pueden hacer llamadas	Está activo el bloqueo de llamadas	Cancele el bloqueo de llamadas
El teléfono no puede conectarse a la red	La tarjeta SIM es inválida	Contacte su operador de telefonía
	El teléfono no está en un área de servicio	Intente entrar al área de servicio el operador
	La señal es muy débil	Muévase a un área con mayor señal
La batería no se puede cargar	El voltaje de carga no concuerda con el del cargador	Asegúrese que la fuente de voltaje coincide con el cargador
	Se está usando un cargador inadecuado	Utilice el cargador específicamente diseñado para su teléfono celular
	Contacto pobre	Asegúrese de conectar correctamente el cargador al teléfono celular

PREMIER®

INSTRUCTION MANUAL
CELPHONE W/TV
CEL-4456TV

DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.
If you need extra support, please write to ***info@premiermundo.com***

CAUTION

RISK OF ELECTRIC SHOCK, DO NOT OPEN

Caution: To reduce the risk of electric shock do not open this device, there are not serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.

This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.

This sign means that there are important instructions of operation and handling in the manual that comes with this device.

PREMIER CUSTOMER SERVICE

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panama:	300-5185
Website	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTE
This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

Content

General Information 4
Profile 4
Safety Information 4
Safety warning and Attentions 4
Your phone 5
Phone overview 5
Functions of Keys 5
Technical specifications 6
Getting started 6
Installing the SIM Cards and the Battery 6
Installing T-Flash Card 7
Charging the Battery 7
Powering On/Off the Mobile Phone 9
Linking to the Network 9
Dialing Calls 9
Using the Headset 9
Input method 9
Icons for Input Methods 10
To Shift Entry Methods 10
Numeric Input 10
English input and numeric input: 10
Inserting a Symbol 10
Using the menu 10
Messaging 10
Phonebook 11
Calendar 12
Call history 12
Bluetooth 12
Services 12
Connectivity 12
Multimedia 12
Camera 12
Video recorder 13
TV 13
FM Radio 13
Audio Player 13
Calculator 13
File manager 13
Settings 14
Display 15
Organizer 15
User profile 16
Games 16
Facebook 16
Ebuddy 16

Yahoo 16
Twitter 16
Lock keypad 17
Power off 17
Appendix 17

General Information

Profile

Please read this pamphlet carefully in order to make your phone in perfect condition.

Our company may change this mobile phone without prior written notice and reserves the final right to interpret the performance of this mobile phone.

Due to different software and network operators, display on your phone may be different, refer to your phone for details.

Safety Information

If your phone has lost or been stolen, notify the telecommunication office the SIM card is disabled (network support is required). This can avoid economic loss caused by unauthorized use.

Please take measures as following to avoid your phone being unauthorized use:

· Set PIN code of SIM card

· Set phone password

Safety warning and Attentions

Safety warning

➢ **ROAD SAFETY COMES FIRST**

Do not use a hand-held phone while driving. Use hands-free fittings when calls are unavoidable while driving. In some countries, dialing or receiving calls while driving is illegal!

➢ **SWITCH OFF IN AIRCRAFT**

Wireless devices can cause interference in aircraft. Using a mobile phone in flight is illegal and risky. Please make sure that your mobile phone is powered off in flight.

➢ **SWITCH OFF BEFORE ENTERING RISKY AREAS**

Strictly observe the relevant laws, codes, and regulations on the use of mobile phones in risky areas. Turn off your mobile phone before entering a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

➢ **OBSERVE ALL SPECIAL REGULATIONS**

Follow any special regulations in force in any area such as hospitals and always switch off your phone whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatuses.

➢ **INTERFERENCE**

The conversation quality of any mobile phone may be affected by radio interference. An antenna is built inside the mobile phone and located below the microphone. Do not touch the antenna area during a conversation, lest that the conversation quality deteriorate.

➢ **QUALIFIED SERVICE**

Only qualified personnel may install or repair phone equipment. Installing or repairing the mobile phone on your own may bring great danger and violates the warranty rules.

➢ **ACCESSORIES AND BATTERIES**

Use only approved accessories and batteries.

➢ **USE SENSIBLY**

Use only in a normal and proper manner.

➢ **EMERGENCY CALLS**

Ensure the phone is switched on and in service, enter the emergency number, e.g. 112, then press the Dial key. Give your location and state your situation briefly. Do not end the call until told to do so.

Note: *Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to network or radio transmission problems. Some networks even do not support the emergency call service. Therefore, do not rely solely on the mobile phone for critical communications such as first aid. Please consult the local network operator.*

Precautions

This mobile phone is well designed with fine art. Please exercise special care when using it. The following suggestions will help your mobile phone survive the warranty period and extend its service life:

- Keep the mobile phone and all its fittings beyond children's reach.
- Keep the mobile phone dry. Keep away from rain, moisture, liquid or other substances that may corrode electronic circuits.
- Do not use or store the mobile phone in dusty places, lest that active parts of the mobile phone be damaged.
- Do not store the mobile phone in a high-temperature place. High temperature will shorten the life of electronic circuits and damage the battery and some plastic parts.
- Do not store the mobile phone in a chilly place. Otherwise, moistures will be formed inside the mobile phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.
- Do not throw, knock or shock the mobile phone, as that will destroy the internal circuits and high-precision components of the mobile phone.

Your phone

Phone overview

Functions of Keys

The mobile phone provides the following keys:

- Dial key
  Press it to originate a call by entering the called number or selecting a contact from the phonebook; or press it to receive an incoming call; or press it in standby state to show the latest call records
- End key
  Press it to end a call being dialed or end an ongoing call; or press it to exit the menu and return to the standby state; or hold it for two or three seconds to power on or off the mobile phone.
- Left and right soft key
  The bottom line on the screen displays the functions of the Left and Right soft key.
- Direction key
  Press them to scroll the options when browsing a function list. In edit state, press direction keys to navigate.
- OK key
  Press it to confirm your selection. In idle screen, long press OK key can turn on/off torch which

situates at the top of the phone.

- Delete key
  Press it to delete a character before cursor.
- Linefeed
  This key helps to switch to another line when the interface is in the edit interface.
- Shift key
  Press this key to switch between input methods.
- Space key
  Press it in the edit interface to get a blank. In idle interface, long press Space key can turn on/off torch which situates at the top of the phone.
- Sym key
  Press it in the edit interface to input a symbol.
- Caps key
  Press it to switch between upper case and lower case.
- Alt
  In edit interface, press it to input an alternative symbol or number.
- **Number keys, letters**
  Press number keys or letter keys to in input or edit state to input numbers or letters;

Technical specifications

Phone
Dimensions (56.73×104.5×14.3):
Weight: With battery: 74g, and without battery: 64g
Lithium battery
Rated capacity: 650 mAH
Continuous standby duration: 75 Hours
Continuous conversation duration: 3.5 Hours

Getting started

Installing the SIM Cards and the Battery

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PIN2, PUK (PIN Unlocking Key), PUK2 (PIN2 Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

Note:

After powering off your mobile phone, wait for a few seconds before removing or inserting an SIM card.

Exercise caution when operating an SIM card, as friction or bending will damage the SIM card.

Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.

Installation

- Hold the End key for a while to power off the mobile phone
- Push the back cover above the battery and remove it.
- Pull the left battery buckle outward and then lift the battery away.
- Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing download, till the SIM card cannot be further

pushed in.

- Aim the positive pole and negative pole of the battery at the battery connector of the mobile phone, and press the left of the battery to install the battery into the battery tank.

Using code

The mobile phone and the SIM cards support sorts of passwords, in order to prevent the phone and the SIM cards from being misused. When you are prompted to input any of the codes mentioned below, just input the correct code and then press the OK key. If you input a wrong code, press the Right soft key to clear it and then input the correct code.

- **Phone lock code**

The phone lock code may be set to prevent your mobile phone from being misused. In general, this code is provided along with the mobile phone by the manufacturer. The initial phone lock code is set to 1234 by the manufacturer. If the phone lock code is set, you need to input the phone lock code when powering on the mobile phone.

- **PIN**

The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

Unlocking methods as follows:

-Input the correct PUK according to the screen tips to unlock the SIM card.

-Then input the new PIN and press the OK key.

-Input the new PIN again and then press the OK key.

-If the input PUK is correct, the SIM card will be unlocked and the PIN will be reset.

Note: *The SIM card will be locked if you input wrong PIN code for three times. To unlock the SIM card, you need to input the PUK. In general, the PUK can be obtained from the network operator.*

- **PUK**

The PUK code (Personal Unlocking Key) is required to change a blocked PIN. It is supplied with SIM card. If not, contact your network operator. If you input wrong PUK code for 10 times, SIM card will be invalid. Please contact the network operator to replace the SIM card.

- **Barring code**

A barring code is required for setting the call barring function. You can obtain this code from the network operator to set the call barring function.

Installing T-Flash Card

The T-Flash card is a pluggable mobile storage card inside the mobile phone.

To install the T-Flash card, open its latch, place its indented side downward, insert the card into the card slot, and then close the latch.

To remove the T-flash card, open its latch and slightly take the card out. And then close the latch.

Note:

1. The mobile phone cannot automatically identify the T-flash card being inserted when the mobile phone is powered on. You must power off the mobile phone and then power it on, so that the phone can identify the T-Flash card.

2. The T-Flash card is a miniature object. Keep it out of the reach of children for fear that children swallow it!

Charging the Battery

The lithium battery delivered with the mobile phone can be put into use immediately after being

unpacked.

Battery level indication:

- Your mobile phone can monitor and display the battery state.
- Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is too low.
- A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.

Using a travel adapter:

- Install the battery into the mobile phone before charging the battery.
- Connect the adapter of the travel charger with the charging slot in the mobile phone. Ensure that the adapter is fully inserted.
- Insert the plug of the travel charger to an appropriate power outlet.
- During the charging, the battery level grids in the battery icon keep flickering till the battery is fully charged.
- It is normal of the battery to become hot during the charging period.
- The battery icon does no longer flicker when the charging process ends.

Note:

Ensure that the plug of the charger, the plug of the earphone, and the plug of the USB cable are inserted in the right direction. Inserting them in a wrong direction may cause charging failure or other problems.

Before the charging, ensure that the standard voltage and frequency of the local mains supply match the rated voltage and power of the travel charger.

Using the Battery

The performance of a battery is subject to multiple factors: radio network configuration, signal strength, ambient temperature, chosen functions or settings, phone fittings, and the voice, data or other application mode you choose to use.

To guarantee the optimal performance of your battery, please stick to the following rules:

- Use only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.
- Power off the mobile phone before removing the battery.
- The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time. In this case, the battery icon does not flicker until a long time after the battery enters the charge status.
- During the charging, ensure the battery is placed in a room temperature environment or in an environment close to room temperature.
- Immediately stop using the battery if the battery produces odor, overheats, cracks, distorts or has other damage, or if the electrolyte leaks.
- The battery wears out with use. A longer charging time is required as the battery is put into use for a long time. If the total conversation duration decreases but the charging time increases even though the battery is properly charged, purchase a standard battery from the OEM or use a battery approved by our company. Using any poor-quality fittings will cause harm to your mobile phone or even incur danger!

Note: *To guarantee your personal safety and protect the environment, do not litter the battery! Return the old battery to the mobile phone manufacturer or place it in specified battery reclamation areas. Do not litter any battery with other rubbish.*

Warning: Short-circuits of the battery may cause explosion, fire, personal injury or other severe consequences!

Powering On/Off the Mobile Phone

Hold the End key for a while to power on the mobile phone. A power-on animation appears on the display screen.
Input the phone lock code and press the OK key if the mobile phone prompts you to input the phone lock code. The original code is 1234
Input the PIN and press the OK key if the mobile phone prompts you to input the PIN. The PIN is provided by the network operator for new opening SIM card.
Enter the standby interface.
To power off the mobile phone, hold the End key for a while.

Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network. After finding a network, the mobile phone enters the standby state. When the mobile phone is registered in the network, the name of the network operator is displayed on the screen. Then you can dial or receive a call.

Dialing Calls

In the standby interface, press number keys to input the area code and the telephone number, and then press the Dial key to dial a call. To end the call, press the End key.

- **Dialing a call to a number in the phonebook**

Enter the phonebook and use the up or down direction keys to find the telephone number you want to call.
Press the Dial key. The mobile phone automatically dials the chosen telephone number.

- **Redialing the last number**

In the standby interface, press the dial key to show the dialed calls.
Press the up or down direction keys to select a number you want to dial and then press the Dial key.

- **Answering incoming calls**

Press the Dial key or the Left soft key to answer an incoming call.
Press the End key to end the current conversation.
To reject an incoming call, press the End key or the Right soft key.
Note: *If the caller can be identified, the mobile phone will present the calling number. If the calling number exists in the phonebook, the mobile phone will present both the name and the phone number of the caller. If the caller cannot be identified, the mobile phone will present the calling number only. You can answer an incoming call when using a function list or browsing the phonebook.*

Using the Headset

It would enter headset mode automatically when you insert headset to the slot. Make sure of inserting it at the bottom of the slot, or you can't use it normally.

Input method

This mobile phone provides two input methods, including English input and numeric input. You can

use these input methods when editing the phonebook, short messages, files and greeting text.

Icons for Input Methods

After you enter an edit window such as a window for editing the phonebook, short messages or the memorandum, an icon is displayed to indicate the current input method:

Numeric input:“123”
English input in upper case:“ABC”
English input in lower case□“abc”

To Shift Entry Methods

Press **ctrl key** to switch between input methods.

Numeric Input

You can input numbers with the numeric input method. Press a number key to input the corresponding number.

English input and numeric input:

The keyboards for English input and numeric input are defined in the following table:

Key	Character or Function	Remarks
Number key 1	W1	
Number key 2	E2	
Number key 3	R3	
Number key 4	S4	
Number key 5	D5	
Number key 6	F6	
Number key 7	Z7	
Number key 8	X8	
Number key 9	C9	
Number key 0	0	
* key	A*	
# key	Q#	

English input:

- To input a blank, press **Space**.
- To clear wrong inputs, press the **delete** key.

Inserting a Symbol

Press the **sym** key to enter the **Select symbol** interface and select a symbol you want.

Using the menu

Messaging

If the short message memory is full, a blinking SMS icon appears on the top of the screen. To normally receive short messages, you need to delete some of the existing short messages.

Write message

Access this menu to create a text message or a multimedia message.

Inbox

Received messages are listed in this menu.

Drafts

From the main menu select "**Messages**" to create text message. You can type a message, and you're also able to insert a pre-defined message from "**Templates**". While writing a message, select "**Options**" to access all the messaging options. You can save your messages that you send often to "**Drafts**".

Outbox

The messages which are sent failed are stored in the Outbox.

Sent messages

Sent messages are listed in this menu.

Delete messages

You can delete messages stored in Inbox, Outbox, Drafts, etc through this function.

Broadcast Message

This network service enables you to receive a variety of text messages, such as broadcast messages about weather forecast or road conditions. At present, few networks provide this service. Please consult the network operator.

- **Receive mode**: Set it to **On** to enable or **Off** to disable cell broadcast service.
- **Channel settings**: Select receiving some types of cell broadcast messages or edit/delete some channel numbers.
- **Languages**: Select the language in which cell broadcast messages are displayed. The selected language, however, may not be supported by the network operator.
- **Read message**: View cell broadcast messages. You can press the **Up** and **Down** direction keys to view these messages.

Message Settings

This function enables you to set the default features about the SMS, MMS and service message.

Phonebook

The mobile phone can store up to 300 telephone numbers. The number of telephone numbers that an SIM card can store depends on the storage capacity of the SIM card. The telephone numbers stored in the mobile phone and in the SIM cards form a phonebook.

After selecting a telephone number in the phonebook, select **Options** to perform the following operations:

- **View**: View the content of the telephone number.
- **Sent text message**: sent text message to this number.
- **Sent multimedia message**: sent multimedia message to this number.
- **Call:** call the current number.
- **IP dial**: IP dial the selected number.
- **Edit**: Edit the telephone number and name.
- **Delete**: Delete the telephone number from the phonebook.
- **Copy**: Duplicate the telephone number from the mobile phone to the SIM card or from the SIM card to the mobile phone.
- **Move**: Move the telephone number to the SIM card if it is stored in the mobile phone or to the mobile phone if it is stored in the SIM card.
- **Send business card:** Select and send contacts information to other recipients via text message, multimedia message or Bluetooth.
- **Mark several**: Mark several phone numbers at a time so that you can perform a same operation on

them.

- **Caller groups**: You can assign contacts to the five default caller groups. For each group, you can edit group name, set caller alert, call ringtone and caller picture.
- **Phonebook setting:** To set some parameters of phonebook.

Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc.

Call history

Through this function, you can view a list of missed calls, dialed call and received calls.

Bluetooth

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.
Note: While using your mobile connecting to other device via Bluetooth, you may be prompted to input a password, and an incorrect password would result in a failed connection. Usually, the password is decidable by one of the pairing devices. In another case, when, for example, you use the mobile to connect to a Bluetooth earphone, the password is depended on the default Bluetooth earphone password.

Services

Internet service

This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way.

- **Homepage:** indicates the default website of the internet
- **Bookmarks:** used to save most commonly-used websites
- **Input Address:** input the website to be searched and press finish button to access to the network directly.
- **Last web address**: you can view your last web address through this function.
- **Recent Pages:** browse the record of the recently browsed web pages.-
- **Settings:** set up WAP-related service

Note: Consulting the local network operator for related fee and specific setup.

STK

STK service is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

Connectivity

Access this interface to set Data account related parameters.

Multimedia

Camera

The phone is provided with a camera, which supports the photographing functions. Roll the phone to align the camera to the picture and then press OK key to capture photos. In the capture interface, you can press left or right direction key to tune exposure value; up or down direction key to zoom in and

zoom out.

Video recorder

This function enables you to record dynamic pictures. In the capture interface, press left or right direction key to tune exposure value; up or down direction key to zoom in and zoom out; OK key to capture videos clip.

TV

You are able to access this menu to watch mobile TV programs and add the programs you like to channel list.

Before you watch TV programs, you'd better select the right area. Then you can search available channels and select channel to play. In TV player interface, you can press * key to start auto search; press # key to switch to full screen play; press I/- or O/+ key to tune volume.

FM Radio

You can use the application as a traditional FM radio with automatic tuning and saved channels. In FM radio interface, you can press left or right direction key to search channels manually, down direction key to play/pause the playing process of the current channel, up direction key to enable auto search (once this is enabled, you can press left or right direction key to search channels automatically). You can press I/- or O/+ key to tune volume.

Audio Player

Use this function to play audio files. By pressing the direction key can you control the playing process of audio player: play/pause□up direction key□, switch to last song/next song □press left or right direction key□, fast forward (press and hold right direction key) and rewind (press and hold left direction key), stop (down direction key), play list(OK key). In audio player interface, you can press I/- or O/+ key to tune volume.

support format : amr midi mp3 wma WAV

Image viewer

You can view the pictures or images through this function.

Video player

You can use this video player to play 3gp/mp4 format video files, and the AVI format video files captured by video recorder can also be played through this function. By pressing the direction key can you control the playing process of video player: play/pause□OK key□, fast forward (press and hold right direction key) and rewind (press and hold left direction key). In video player interface, you can press I/- or O/+ key to tune volume□# key to switch to full screen play.

Sound recorder

The phone support WAV and AMR. The AMR takes the compression algorithm. So in the same memory condition, it has longer recording time than WAV.

Calculator

The calculator can add, subtract, multiply and divide. To use the calculator:

- Press the up, down, left and right key to select ＋, －, ×, ÷, ＝ respectively.
- Press right soft key to delete the figure.

File manager

The phone provides a certain space for users to manage files and supports the T-Flash card. The capacity of the T-Flash card is selectable. You can use the file manager to conveniently manage various

directories and files on the phone and the T-Flash card.

Open

Choose **File manager** to enter the root directory of the memory. The root directory will list the default folders, new folders and user files. When the mobile phone is powered on for the first time or when you have not changed the directory, the root directory contains the default folders only.

Format

You can use this function to format all the data in the memory. The system will re-create a default folder. The formatted data cannot be recovered. Therefore, think twice before using the formatting function.

Settings

Triple SIM switch

Manually selected by user and automatically decided by SIM cards are available for you to choose. You can select one of them as per your needs.

Triple SIM Settings

Triple-SIM refers to three SIM card slots, and the three cards can standby at the same time or set one of them to display on the idle screen.

Phone Settings

- **Time and date:** set the date format, the time format, and detail time of the location.

Note: *If you remove the battery from the mobile phone or if the battery energy was exhausted a long time ago, you may need to reset the date and time when re-inserting the battery or powering on the mobile phone after recharging.*

- **Schedule power on/off:** Set the time when the mobile phone will be automatically powered on or off.

Alert: Before entering an area where the use of mobile phones is forbidden, make sure that the scheduled power-on function is deactivated to avoid accidents.

- **Language:** Select the display language for the mobile phone.
- **Pref. input method**: Select an input method as preferred input method as per your need.
- **Shortcuts:** Access this menu to select shortcuts function to display on idle screen.
- **Flight mode:** when this function is engaged, it will suspend many of the device's signal transmitting functions – thereby disabling the device's capacity to place or receive calls or text messages– while still permitting use of other functions that do not require signal transmission (e.g., games, built-in camera, MP3 player.)
- **UTRA settings**: Select SIM1 or SIM2 as needed.
- **Torch**: Turn on/off torch as per your need. In idle screen, long press OK key can turn on/off torch which situates at the top of the phone.
- **Color LED**: Turn on/off color LED as per your need.
- **Color LED Style:** Three styles are available for you to choose. You can select one of them as per your need.

Call Setting

- **Call waiting**: After you choose Activate, the mobile phone will contact the network. A moment later, the network will make a response and send a message to acknowledge your operation. If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.
- **Call diverts:** this network function enables you to forward incoming calls to another number you have previously specified.
- **Call barring:** The call barring function enables you to bar calls as needed. When setting this function, you need to use a network barring code, which can be obtained from the network operator.

If the code is wrong, an error message will be prompted on the screen. After selecting a call barring option, continue to select Activate or Deactivate. The mobile phone will prompt you to input the call barring code and then contact the network. A moment later, the network will make a response and send the operation results to the mobile phone.

- **Line switching**: Switch to Line 1 or Line 2. By default, Line 1 is used.

Note: If you choose Line 2, dialing may fail. This depends on the implementation of the network operator.

- **Auto redial**: Set it to **On** or **Off** to enable or disable auto redial. If you set **Auto redial** to **On**, the mobile phone will automatically redial the number a moment later if the called party does not reply. The number of auto redial times can be set to a maximum of 10. In the auto redial period, you cannot dial other numbers. To end the auto redial process, press the **End** key.

***Note**: This function requires support from the network operator to which the SIM card is registered.*

- **IP dial**: Activate/deactivate the IP dial function and add/edit IP numbers.
- **Call time reminder**: To set single or circle tone in a call to make you know the time.
- **Answer mode**: Set answer mode as per your need.

Network Settings

Contact the network operator to obtain the following network services:

- **Network selection:** Set Network selection mode to Automatic or Manual. Automatic is recommended. When Network selection mode is set to Automatic, the mobile phone will prefer the network where the SIM card is registered. When Network selection mode is set to Manual, you need to select the network operator's network where the SIM card is registered.
- **Preferred networks:** Select the preferred networks. By default, the network where the current SIM card is registered will be displayed.

Security Settings

This function provides you with related settings about safety use

- **SIM1 security**
  - **PIN lock:** To activate PIN lock, you need to input the correct PIN code. If you set PIN lock to On, you need to input the PIN each time you power on the mobile phone. In the case you input a wrong PIN for three consecutive times, you need to input the PIN Unblocking Key (PUK). The PUK is used to unlock and change the locked PIN. To obtain the PUK, contact the network operator.
  - **Change PIN:** To change PIN code of SIM card.
  - **Change PIN2:** To change PIN2 code of PIN code.
- **Phone security**
  - **Phone lock:** The function enables you to lock/unlock the phone. Once this function is enabled, correct password is required when the phone is locked. The password is 4 to 8 digits.
  - **Change password:** to change phone password.
- **Auto keypad lock:** The function enables you to lock/unlock the keypad. Setting the auto locking time that 5s, 30s, 1min or 5mins is available. The keypad will be auto locked with no operation during the period.

Restore Factory Settings

Use this function to restore factory settings. The preset password is 1234.

Display

Users can access this item to set wallpaper, screen saver, power on/off display, etc.

Organizer

Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important

appointments, etc. Days with events entered will be marked.

Alarm

Five alarm clocks are set but deactivated by default. You can activate one, multiple or all of them as needed. For each alarm clock, the ringing date and the ringing time can be set.

Calculator

The calculator can add, subtract, multiply and divide. To use the calculator:

- Press the up, down, left and right key to select +, −, ×, ÷, = respectively.
- Press right soft key to delete the figure.

Stopwatch

Stopwatch is simple application for measuring time with possibility to register several results and suspend/resume measurement.

User profile

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into five scenarios: **General**, **Silent, Meeting**, **Outdoor and My style**.

When you insert an earpiece to the mobile phone, the mobile phone automatically enters the Headset mode. There is no option for activating the Headset mode on the screen. For details on operation, refer to **General**. If you set **Headset** > **Customize** > **Answer mode** to **Auto**, incoming calls will be automatically answered.

Activate

Select **Activate** to activate the selected mode.

Customize

After choosing one of the above five modes, select **Customize** to edit the following items: Alert type, Ring type, incoming call ringtone, ringtone volume, message ringtone, keypad tone, power on/off tone, etc.

Reset

Use this function to restore factory settings of user profile.

Games

A game named F1 race is embedded in this menu. For specific operation, please refer to ‘help’ option of the game.

Facebook

Log on Facebook through a web.

Ebuddy

Log on Ebuddy through a web.

Yahoo

Log on Yahoo through a web.

Twitter

Log on twitter through a web.

Lock keypad

Select this function to lock keypad. When the keypad is locked, you can press right soft key then **space** key to unlock keypad.

Power off

Select this function to power off the mobile phone. When the phone is powered off, you can long press end key to power on it.

Appendix

Appendix 1 Troubleshooting

If you find exceptions when operating the mobile phone, restore the factory settings and then refer to the following table to solve the problem. If the problem persists, contact the distributor or service provider.

Fault	Cause	Solution
SIM card error	The SIM card is damaged.	Contact your network service provider
	The SIM card is not in position.	Check the SIM card
	The metal face of the SIM card is polluted.	Clean the SIM card with a clean cloth
Poor received signal quality	Signals are obstructed. For instance, radio waves cannot be effectively transmitted nearby a high building or in a basement.	Move to a place where signals can be effectively transmitted
	Line congestions occur when you use the mobile phone in high-traffic hours	Avoid using the mobile phone in high-traffic hours

The mobile phone cannot be powered on	The battery energy is exhausted.	Charge the battery
Calls cannot be dialed	Call barring is activated	Cancel call barring
The mobile phone cannot connect the network	The SIM card is invalid	Contact your network service provider
	The mobile phone is not in a service area of the GSM network	Move to the network operator's service area
	The signal is weak	Move to a place where the signal quality is high
The battery cannot be charged	The charging voltage does not match the voltage range indicated on the charger	Ensure the charging voltage matches the voltage range indicated on the charger
	An improper charger is used	Use the charger specially designed for the mobile phone
	Poor contact	Ensure the charger plug is in good contact with the mobile phone